

# BIG BIKE PARTS<sup>®</sup>

# INSTALLATION INSTRUCTIONS

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 20-521/20-521T/20-522T

WINDSHIELD

11/9/2018

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

TOOLS NEEDED: PHILLIPS SCREWDRIVER



5MM ALLEN WRENCH

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**

**ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.**

## INSTALLATION:

1. TURN THE BIKE ON AND RAISE THE WINDSHIELD TO ITS HIGHEST POSITION.
2. USING A PHILLIPS SCREWDRIVER PRESS IN ON THE CENTER OF BOTH PLASTIC RIVETS TO RELEASE THEM. SEE FIG.1
3. REMOVE BOTH PLASTIC RIVETS AND REMOVE THE RIGHT AND LEFT TRIM FROM THE FRONT SIDE OF THE WINDSHIELD.
4. AFTER REMOVING THE PLASTIC RIVETS PUSH THE PIN IN THE CENTER BACK SO THEY ARE READY TO REINSTALL.
5. USING A 5MM ALLEN WRENCH REMOVE THE FOUR ALLEN SCREWS AND WASHERS SHOWN IN FIG. 2
6. INSTALL THE NEW WINDSHIELD AND THE WINDSHIELD TRIM IN REVERSE ORDER.



# BIG BIKE PARTS<sup>®</sup>

# INSTALLATION INSTRUCTIONS

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 20-521/20-521T/20-522T

WINDSHIELD

11/9/2018

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

TOOLS NEEDED: PHILLIPS SCREWDRIVER

5MM ALLEN WRENCH

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**

**ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.**

## INSTALLATION:

1. TURN THE BIKE ON AND RAISE THE WINDSHIELD TO ITS HIGHEST POSITION.
2. USING A PHILLIPS SCREWDRIVER PRESS IN ON THE CENTER OF BOTH PLASTIC RIVETS TO RELEASE THEM. SEE FIG.1
3. REMOVE BOTH PLASTIC RIVETS AND REMOVE THE RIGHT AND LEFT TRIM FROM THE FRONT SIDE OF THE WINDSHIELD.
4. AFTER REMOVING THE PLASTIC RIVETS PUSH THE PIN IN THE CENTER BACK SO THEY ARE READY TO REINSTALL.
5. USING A 5MM ALLEN WRENCH REMOVE THE FOUR ALLEN SCREWS AND WASHERS SHOWN IN FIG. 2
6. INSTALL THE NEW WINDSHIELD AND THE WINDSHIELD TRIM IN REVERSE ORDER.

