

FRONT FAIRING COVER 335

PARTS INCLUDED:

FRONT FAIRING COVER CHROME ————— 1
ALCOHOL PAD ————— 1

WARNING:

IGNORING THE INSTRUCTION
MAY RESULT IN POTENTIAL
SERIOUS INJURY, DEATH OR
MATERIAL DAMAGE.

LIMITED WARRANTY:

PRODUCTS ARE WARRANTED TO BE FREE OF DEFECTS IN MATERIAL AND WORKMANSHIP FOR 1 (ONE) YEAR FROM DATE OF PURCHASE BY THE CONSUMER.

CUSTOMER MUST SHOW PROOF OF PURCHASE FOR WARRANTY.

TWINART SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL AND INCIDENTAL DAMAGES.

THE PRODUCTS MUST BE INSTALLED PROPERLY AND OPERATED UNDER NORMAL CONDITIONS.

1. PARK ON A LEVEL SURFACE AND SHUT OFF THE MOTORCYCLE.

2. CLEAN THE MOUNTING SURFACES WITH HOT WATER AND SOAP TO REMOVE ALL DIRT AND DEBRIS. THEN, THOROUGHLY CLEAN THE SURFACE WITH INCLUDED ALCOHOL PAD.

***NOTE: DO NOT INSTALL IF THE TEMPERATURE IS BELOW 50°F. THE ADHESIVE WILL NOT CURE PROPERLY.**

3. REMOVE THE RED ADHESIVE BACKING AND INSTALL THE COVER. USING RAZOR KNIFE IS HELPING TO REMOVE BACKER EASILY. PRESS THE COVER FIRMLY ONTO THE SURFACE FOR 60 SECONDS OR MORE. THE ADHESIVE CURES WITHIN 24 HOURS.