

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright © 2021 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-966

KICKSTAND BASE

FITMENT: HONDA GOLDWING GL1800 2018-NEWER

1/19/2021

TOOLS NEEDED: CLEAN RAG

REMOVABLE THREAD LOCK

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. USE REMOVABLE THREAD LOCK WHEN INSTALLING ALL SCREWS.
ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

INSTALLATION:

1. WITH THE BIKE ON THE CENTER STAND, MOVE THE KICKSTAND TO THE DOWN POSITION (FIG. 1).
2. CLEAN ANY DIRT OR DEBRIS FROM THE BOTTOM OF THE KICKSTAND AND WIPE WITH A CLEAN RAG (FIG. 1).
3. REMOVE THE KICKSTAND BASE FROM THE PACKAGING.
4. SLIDE THE KICKSTAND BASE ONTO THE END OF THE OEM KICK STAND (FIG. 2).
5. PLACE A SMALL DROP OF REMOVABLE THREAD LOCK ON THE THREADS OF THE M4-0.7X8MM SET SCREW.
6. TIGHTEN THE SET SCREW UNTIL THE KICKSTAND BASE IS SECURE (FIG. 2). (DO NOT OVER TIGHTEN)



NOTICE

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright © 2021 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-966

KICKSTAND BASE

FITMENT: HONDA GOLDWING GL1800 2018-NEWER

1/19/2021

TOOLS NEEDED: CLEAN RAG

REMOVABLE THREAD LOCK

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. USE REMOVABLE THREAD LOCK WHEN INSTALLING ALL SCREWS.
ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

INSTALLATION:

1. WITH THE BIKE ON THE CENTER STAND, MOVE THE KICKSTAND TO THE DOWN POSITION (FIG. 1).
2. CLEAN ANY DIRT OR DEBRIS FROM THE BOTTOM OF THE KICKSTAND AND WIPE WITH A CLEAN RAG (FIG. 1).
3. REMOVE THE KICKSTAND BASE FROM THE PACKAGING.
4. SLIDE THE KICKSTAND BASE ONTO THE END OF THE OEM KICK STAND (FIG. 2).
5. PLACE A SMALL DROP OF REMOVABLE THREAD LOCK ON THE THREADS OF THE M4-0.7X8MM SET SCREW.
6. TIGHTEN THE SET SCREW UNTIL THE KICKSTAND BASE IS SECURE (FIG. 2). (DO NOT OVER TIGHTEN)



NOTICE

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.