



Goldstrike Adjustable Passenger Comfort Peg Mounts

Parts Included:

1	Left Side Arm Mount	1
1	Right Side Arm Mount	
2	Rail pegs	
2	Click peg adapters	
2	Mount arms	
2	Clevis	

Hardware kit including:

2	D springs
2	3/8-24 x 1-1/8" SHCS
4	3/8" High Collar lock washers
2	3/8-16 x 1-3/8" SHCS
2	3/8-24 X 7/8" SHCS
2	5/16-18 x 1" SHCS
2	Narrow 5/16" flat washers
2	Tab Springs
2	4-40 x 3/8" BSCS

Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has had time to cool before installation. Place on center stand if available.
2. Remove OEM Swingarm Pivot Cover. Set screws aside for reuse. (Fig. 1)



3. Install Arm Mount using original screws, being sure to use thread locking fluid, torque to 5.2 N-m, 3.8 ft-lbs. (Fig. 2)

4. Assemble tab springs into clevis using 4-40 x 3/8" BSCS and a hex wrench. (Fig. 3 & 4)



WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure.

Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit our website Ciro3d.com for our complete warranty policy.

5. Install click peg adapters with a D spring and 3/8-24 x 1-1/8" SHCS into clevis. Torque to 25-35 ft-lbs. (Fig. 5)



6. Assemble components per figure shown. It may be helpful to keep things slightly loose until final position is found. (Fig. 6)



7. Install loosely assembled mount arms/clevis/peg to the Side Arm Mounts already on the motorcycle. Determine final position. Be sure to check clearance of rider's feet, and passenger floorboard operation. (Fig. 7)



8. Tighten all fasteners and repeat all steps on other side.

5/16 fasteners to 25-35 ft-lbs

3/8 fasteners to 36-42 ft-lbs