

BIG BIKE PARTS®		INSTALLATION INSTRUCTIONS	
Copyright © 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. HG18SBO	SADDLEBAG ORGANIZER
8/26/2020		FOR HONDA GOLDWING GL1800 2018-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p>INSTALLATION</p> <ol style="list-style-type: none"> STARTING ON THE LEFT SIDE, TEST FIT THE LEFT SADDLEBAG ORGANIZER IN THE LEFT SADDLEBAG LID NOTING THE AREA TO BE CLEANED. REMOVE THE ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE LEFT SADDLEBAG LID AREA WHERE THE LEFT SADDLEBAG ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY. LOOKING AT THE BOTTOM OF THE LEFT SADDLEBAG ORGANIZER, REMOVE THE CLEAR BACKING FROM THE HOOK AND LOOP. CAREFULLY SET THE LEFT SADDLEBAG ORGANIZER BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP. REPEAT STEPS 1-4 ON THE RIGHT SIDE. LET THE BIKE SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE. REMOVE BOTH SADDLEBAG ORGANIZERS BY SEPARATING THE HOOK AND LOOP. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE SADDLEBAG LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS. REATTACH BOTH SADDLEBAG ORGANIZERS. 			

BIG BIKE PARTS®		INSTALLATION INSTRUCTIONS	
Copyright © 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. HG18SBO	SADDLEBAG ORGANIZER
8/26/2020		FOR HONDA GOLDWING GL1800 2018-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p>INSTALLATION</p> <ol style="list-style-type: none"> STARTING ON THE LEFT SIDE, TEST FIT THE LEFT SADDLEBAG ORGANIZER IN THE LEFT SADDLEBAG LID NOTING THE AREA TO BE CLEANED. REMOVE THE ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE LEFT SADDLEBAG LID AREA WHERE THE LEFT SADDLEBAG ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY. LOOKING AT THE BOTTOM OF THE LEFT SADDLEBAG ORGANIZER, REMOVE THE CLEAR BACKING FROM THE HOOK AND LOOP. CAREFULLY SET THE LEFT SADDLEBAG ORGANIZER BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP. REPEAT STEPS 1-4 ON THE RIGHT SIDE. LET THE BIKE SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE. REMOVE BOTH SADDLEBAG ORGANIZERS BY SEPARATING THE HOOK AND LOOP. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE SADDLEBAG LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS. REATTACH BOTH SADDLEBAG ORGANIZERS. 			