

Install kit

8m x 16m bolts = 2

12V Heat Adapter

Ultimate GL1800 Goldwing (2018 and Newer) Installing Heated Seat on Bike without OEM Heat

MAIN SEAT:

1. Open saddlebags
2. Remove side covers.
3. Remove bolts holding front of seat to bike on both sides (6mm hex key).
4. Pull straight up on front of seat. Then pull entire seat forward.
5. Install included 12v heat adapter in fuse box as shown (Red wire goes in top location). Run wire from adapter on inside of frame (pic 1).
6. **To install your new seat:** Plug in your new seat to heat adapter. Then, hold nose up and slide seat backward. Let front of seat down and install new supplied bolts that hold seat to bike on both sides.
7. Reinstall side covers and close saddlebags.

Pic 1



Questions?

877-672-0288

sales@ultimateseats.com

www.ultimateseats.com

01/15/2020