

Install kit

8m x 16m bolts = 2

**Ultimate GL1800 Goldwing  
(2018 and Newer)  
Installing Non Heated Seat on Bike without OEM Heat**

**MAIN SEAT:**

1. Open saddlebags
2. Remove side covers.
3. Remove bolts holding front of seat to bike on both sides (6mm hex key)
4. Store OEM bolts.
5. Pull straight up on front of seat. Then pull entire seat forward and up.
6. To install your new seat - hold nose up and slide seat backward. Let front of seat down and install new supplied bolts that hold seat to bike on both sides.
7. Reinstall side covers and close saddlebags.

**Questions? 1-877-672 0288**

[sales@ultimateseats.com](mailto:sales@ultimateseats.com)

[www.ultimateseats.com](http://www.ultimateseats.com)

1/15/2020