

# SHAD

## HONDA GL 1800 GOLDWING '18

KIT TOP HOGL15T



1 262348 x1



2 260564 x2  
Ø16 Ø9 x 33



3 304230 x2  
M8 x 60 DIN 7991



4 303025 x4  
Ø10



5 261598 x2  
Ø14 Ø9 x 48



6 304331 x2  
M8 x 75 DIN 7991

### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

