



INSTALLATION

ROTOR COVER REFLECTOR CONVERSION 7455

FOR GL1800

FITS '01-'05 GL1800. '06-UP GL1800'S REQUIRE P/N 7300 (SOLD SEPARATELY)

PART #	INCLUDED
607455L	1 Led Conversion Light – Left
607455R	1 Led Conversion Light – Right
401209	1 Dielectric Grease
607312P	2 Y-Connector Plugs
407455	2 Male Connector Housings
400815	4 4" Nylon Cable Ties
307455	1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

8mm wrench, 5mm Allen wrench, Small pliers

PROCEDURE

STEP 1 Remove the chrome fork covers from the motorcycle.

STEP 2 Remove the stock reflectors from the fork covers.

STEP 3 Install the LED conversion lights in place of the reflectors. The wires will pass through one of the holes in the fork cover used to mount the stock reflector. The stock nut and washer will be reused. We suggest the orientation shown in PIC.1. Re-install the chrome fork covers.

STEP 4 "Peel back" the rubber boot at the base of each of the rear view mirrors. The turn signal light wiring and connector plug will be exposed.

STEP 5 Neatly route the wires so the terminated ends come out of the fairing at the rear view mirror bases. We suggest routing the wires along the brake hoses to the lower fork clamps and binding them with nylon cable ties. Be sure the remaining lengths of wire leading to the mirror bases are out of harms way. Remember to take into account the movement of the front end - both suspension and steering.



-cont.-

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



ATTENTION! Be sure to leave sufficient slack in the wiring harness to allow for extension of the forks. If there is not enough wire to allow for movement, the wiring harness will be damaged!

STEP 6 Locate the connection plug between the mirror mounted turn signals and the fairing. Separate the plug, and install the supplied "Y" adapter plug in line. If you have other Küryakyn products like Stealth Lightbars and LED Mirror Lights, there will already be one "Y" connector in place. This connector can be added to the existing one.

STEP 7 Insert the pins into male connector housing so the following color wires join as follows (remember the housing only plugs in one way!):

Y-Connector Plug
black (ground)
red (running light)
white (turn signal)

LED Conversion Light
black(ground)
green (running light)
red (turn signal)

STEP 8 Plug the rotor light into one of the small plugs on the "Y" connector (the remaining one will be used for other Küryakyn accessories). Replace the rubber boots around the base of the mirrors.

Ride On!