

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

FOR ADHESIVE CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

INSTALLATION:

1. **CHECK** – CHECK FIT OF PART SO YOU KNOW HOW IT GOES ON.
2. **CONTOUR** – THE PART MAY NEED TO BE TWEAKED TO FIT PROPERLY. BE CAREFUL WITH PART SO NOT TO BREAK.
3. **CLEANLINESS** – USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT FREE RAG WILL PREPARE THE SURFACE.
4. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
5. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

FOR ADHESIVE CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

INSTALLATION:

1. **CHECK** – CHECK FIT OF PART SO YOU KNOW HOW IT GOES ON.
2. **CONTOUR** – THE PART MAY NEED TO BE TWEAKED TO FIT PROPERLY. BE CAREFUL WITH PART SO NOT TO BREAK.
3. **CLEANLINESS** – USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT FREE RAG WILL PREPARE THE SURFACE.
4. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
5. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

FOR ADHESIVE CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

INSTALLATION:

1. **CHECK** – CHECK FIT OF PART SO YOU KNOW HOW IT GOES ON.
2. **CONTOUR** – THE PART MAY NEED TO BE TWEAKED TO FIT PROPERLY. BE CAREFUL WITH PART SO NOT TO BREAK.
3. **CLEANLINESS** – USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT FREE RAG WILL PREPARE THE SURFACE.
4. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
5. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

FOR ADHESIVE CHROME ACCESSORIES

Copyright© 2001 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.©

INSTALLATION:

1. **CHECK** – CHECK FIT OF PART SO YOU KNOW HOW IT GOES ON.
2. **CONTOUR** – THE PART MAY NEED TO BE TWEAKED TO FIT PROPERLY. BE CAREFUL WITH PART SO NOT TO BREAK.
3. **CLEANLINESS** – USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT FREE RAG WILL PREPARE THE SURFACE.
4. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
5. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.

FAILURE TO INSTALL AN ACCESSORY AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.