

6/12/2015

TOOLS NEEDED:	PLIERS (1 & 2)	RUBBING ALCOHOL (1 & 2)	LINT FREE TOWEL (1 & 2)	1/8" DRILL BIT (2)	DRILL (2)
	SCISSOR (2)	PHILLIPS SCREWDRIVER (2)	MASKING TAPE (1 & 2)	TAPE MEASURE (2)	PENCIL (2)

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**(1) INSTALLATION USING HOOK AND LOOP:**

1. USING A PLIERS BEND THE TABS ON THE BOTTOM OF EACH FENDER BRA AS SHOWN IN FIG. 1. LEAVE THE TAB OPEN ENOUGH THAT THEY WILL SLIP ONTO THE BOTTOM OF EACH FENDER.
2. LEAVING THE SUPPLIED HOOK ATTACHED TO ONE OF THE BRAS PLACE THE BRA ON THE TRIKE FENDER IN THE DESIRED POSITION. IT MAY HELP TO USE A PIECE OF MASKING TAPE TO MARK THE TOP OF THE BRA ON THE FENDER.
3. REMOVE THE BRA AND USING A LINT FREE TOWEL AND RUBBING ALCOHOL CLEAN THE AREA ON THE FENDER WHERE THE HOOK WILL ATTACH.
4. REMOVE THE MASKING FROM THE PIECE OF HOOK AND INSTALL THE BRA. USE PRESSURE ON THE AREA OF THE HOOK TO HELP ATTACH THE ADHESIVE.
5. REPEAT THE STEPS ABOVE FOR THE OTHER BRA.
6. LET TRIKE SIT FOR 24 HOUR TO LET THE TAPE CURE FOR USING.

(2) INSTALLATION USING SNAPS:

1. USING A PLIERS BEND THE TABS ON THE BOTTOM OF EACH FENDER BRA AS SHOWN IN FIG. 1. LEAVE THE TAB OPEN ENOUGH THAT THEY WILL SLIP ONTO THE BOTTOM OF EACH FENDER.
2. USING A SCISSOR CUT THE LOOP TO EXPOSE THE SNAPS AS SHOWN IN FIG. 2.
3. CLEAN THE AREA ON BOTH FENDERS WHERE THE BRAS ARE GOING TO BE MOUNTED.
4. PLACE ABOUT A 9 INCH LONG PIECE OF MASKING TAPE SO THAT THE CENTER OF THE TAPE IS 9 INCHES ABOVE THE BOTTOM OF THE FENDER.
5. HOOK ONE OF THE BRAS ON THE BOTTOM OF THE FENDER AND PULL IT TIGHT INTO PLACE. USE A PENCIL TO MARK THE CENTER POINT OF EACH SNAP.
6. USING A 1/8" DRILL BIT DRILL A HOLE AT EACH CENTER MARK ON THE FENDER.
7. USING A PHILLIPS SCREWDRIVER INSTALL BOTH MALE SCREW SNAPS ON THE FENDER.
8. INSTALL THE BRA.
9. REPEAT THE STEPS ABOVE FOR THE OTHER BRA.

