



Mounting Suggestions Honda Gold Wing 1800 Passenger Backrest without Heat 2001-13

Removal of Stock Passenger Backrest

1. Open Tour Pak and remove 2 stock backrest mounting screws (fig. 1).
2. Close the Tour Pak and lift backrest up and off.



Installation of Mustang Backrest

1. Slide backrest brackets into Tour Pak recesses (fig. 2).
2. Open Tour Pak and align mounting holes in Tour Pak to those on the backrest .
3. Secure using supplied ¼-20 screws (fig. 3).



**Enjoy the comfort of your new
Mustang Passenger Backrest!**



These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "[Support](#)".

Refers to part numbers: 79905