

INSTALLATION INSTRUCTIONS

PART NO. 52-944

BUNGEE SEAT TIE DOWN SET

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

1/3/2019

TOOLS NEEDED:	6MM ALLEN WRENCH	12MM SOCKET	DRILL	1/4" DRILL BIT	4MM ALLEN WRENCH
	10MM DEEP WELL SOCKET	MASKING TAPE	PENCIL		

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**ESTIMATED INSTALLATION TIME: 30 TO 45 MIN.****INSTALLATION:**

1. WITH BOTH SADDLEBAGS OPEN, REMOVE THE SIDE PANELS BY PULLING STRAIGHT OUT ON THEM (**FIG. 1**).
2. USE A 6MM ALLEN WRENCH TO REMOVE THE TWO SEAT BOLTS (**FIG. 2** SHOWS LEFT SIDE).
3. DISCONNECT THE SEAT WIRE HARNESS PLUG LOCATED UNDER THE RIGHT SIDE PANEL (**FIG. 3**). REMOVE THE SEAT BY LIFTING UP ON THE FRONT OF THE SEAT AND PULLING TOWARDS THE FRONT OF THE BIKE.
4. USE A 12MM SOCKET TO REMOVE THE TWO BOLTS MOUNTING THE LEFT GRAB HANDLE TO THE BIKE FRAME (**FIG. 4**).
5. DISCONNECT THE CABLE FROM THE LEFT GRAB HANDLE BY CAREFULLY REMOVING THE WHITE CABLE HOLDER FROM THE HOLDING TABS ON THE INSIDE OF THE LEFT GRAB HANDLE (**FIG. 5**). ONCE CABLE HOLDER IS FREE, PULL THE TENSION SPRING BACK AND SLIDE THE CABLE OUT OF THE SLOTS IN THE LATCH (**FIG. 5**).
6. REMOVE LEFT GRAB HANDLE AND SET ON A CLEAN SOFT SURFACE TO PREVENT SCRATCHING.
7. PLACE A PIECE OF MASKING TAPE ON THE SURFACE SHOWN IN **FIG. 6**.
8. USE **FIG. 6** TO MEASURE AND MARK THE HOLES TO DRILL IN THE LEFT GRAB HANDLE.
9. DRILL TWO HOLES ON THE MARKS THAT YOU MADE ON THE LEFT GRAB HANDLE WITH A 1/4" DRILL BIT.
10. USE TWO OF THE SUPPLIED SCREWS AND LOCKNUTS TO FASTEN THE LEFT SEAT TIE DOWN IN PLACE. *NOTE: INSTALL SCREW FROM THE TOP WITH THE NUT UNDERNEATH THE GRAB HANDLE.*
11. INSTALL THE LEFT GRAB HANDLE ON THE BIKE IN REVERSE ORDER.
12. REPEAT STEPS 4-11 ON THE RIGHT GRAB HANDLE. *NOTE: RIGHT GRAB HANDLE DOES NOT HAVE A CABLE.*
13. REASSEMBLE THE REST OF THE BIKE IN REVERSE ORDER.



