

RADIATOR SLOT TRIMS 370

Parts included:

Radiator Slot Trim Left Upper Side	1
Radiator Slot Trim Left Lower Side	1
Radiator Slot Trim Right Upper Side	1
Radiator Slot Trim Right Lower Side	1
Adhesion Promoter Packets	2

WARNING:

Ignoring the instruction may result in potential serious injury, death or material damage.

1. Park and Shut down the bike.
2. Clean the mounting surfaces.
3. Test fit items to familiarize left(upper&lower) and right(upper&lower). LH or RH marks on the back side of items. RH is throttle side.
4. Apply included adhesive promoters to mounting surfaces. Mounting surfaces must be without wax, oil and residue.
Do not install if the temprature is below 50 F. The adhesive will not cure properly.
5. After place the pieces, apply pressure for 60 seconds. The adhesive cures within 24 hours.

Limited Warranty:

Products are warranted to be free of defects in material and workmanship for 1 (one) year from date of purchase by the consumer.

Customer must show proof of purchase for warranty.

Twinart shall not be liable for any consequential and incidental damages.

The products must be installed properly and operated under normal conditions.