
25LED INSTALLATION:

This is a special unit designed for a split voltage input of 6 volts for low intensity running light and 12 volts step-up for the brakes. **25LED** modulator fits the OEM Wing-light for the GL1500 SE models.



25LED can be plugged in-line with the connector on the back of the trunk lid as shown. Use Velcro strip to mount it.

2-pin input connector is polarized to match with Gold Wing 1500 wiring. The output pins are protected internally, so reverse connection will not harm the electronics. IF the spoiler LEDs do not come on, check the output pins for polarity and connection.

The Running Light Intensity Adjustment is not available on this unit.

- The step-up regulator of the SE models need minimum of 12.6 volts input to function correctly. *tailBlazer* may not execute complete 4-sec flash cycle without the engine running
- To minimize false triggering from CB transmit function, reroute the coaxial cable of the antenna which runs along the left hinge of the trunk alongside the LED power wire. Separate them as much as possible to eliminate any cross talk.