

## TRIM LINE ARM KIT FOR CYBERCHARGER ®

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.




## Included Items:

- 1 Right narrow wing
- 1 Left narrow wing
- 1 Support leg

- 1. Detach Cybercharger wire connection at base of unit. Remove collet nut on back and remove from ball mount.
- 2. Lift cam lever and unscrew until it releases from threaded T nut. Wings and springs will be released. Set parts aside. Fig. 1
- 3. Remove 4 long screws and 1 short screw from back of unit and set aside. Fig. 2
- 4. Remove back of unit and lift out old support leg. Fig. 3
- 5. Place new support leg into place making sure to set same notch on both sides. Support leg can be adjusted later. Fig. 4
- 6. Place back on and replace 4 long screws and tighten.
- 7. Insert short screw into back but wait to tighten till support leg is adjusted to right position for your phone. Tighten screw to lock.





FCC STATEMENT Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measurement encouraged to try to correct the interference by one or more of the following measurement or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference. And (2) this device may not experienced the received interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.







- 8. Insert springs into wings, Fig. 5. With phone in place decide which position of wings clears your phones side buttons best before inserting cam lever. Fig. 6
- 9. Reinstall cam lever assembly. Snug up to phone and lower cam arm to lock, The cam arm can be installed on either right or left side based on user preference.









